

# Gluing Instructions

**DO NOT GLUE BETWEEN THE TRAYS**



STEP 1: Lay trays out per included drawing. Trays should have roughly a 1/8" Gap, There is a planned air gap in the end to allow for expansion. Make sure all trays are sitting level before moving on to the next step.



Step 2: Place glue tube in caulking gun and cut open end (before screwing on nozzle) to prepare to glue.



Step 3: Run a bead of glue filling up the 1/8" gap you left, allow extra to run down the main drainage channel. Use a small utensils such as a small piece of plastic or metal pipe to smooth glue in main drainage channel, Making sure there is a seam sealed on both ends and no large globs blocking water flowage. You may have to repeat this 1 or 2 times after a few minutes. DO NOT Smooth glue on the top of the gap, let it settle by gravity only smooth glue in the drainage channel.

**DO NOT GLUE BETWEEN THE TRAYS**